


# CFB Cosmetics Nebulizer

Our new Nebulizer is a great way to stay ahead of your studio rooms climate. It was never this easy to adjust your studios air humidity and create the best working atmosphere. Before operating the nebulizer, please read the instruction carefully to ensure the best possible performance.

## Part Identification



## Suggested Use

- Use distilled or purified water.  
Both life cycle and performance of the device may shorten depending on water quality and content.
- Following types of the water shall be avoided due to its high mineral content:  
tap water, mineral water, geothermal water, acidulated water, alkaline ionized water.
- Do not mix the water with any other substance such as lotion, aromatic oil, or perfume.


## Preparation Before use



1. Pull the water tank out of the device and open the cap of water tank.



2. Fill the water tank with distilled water or pure water.



3. Put water tank back into device.

1. Plug your device into the power socket.

2. Press the touch switch to turn on the device, UV light will illuminate and buzzer respond.

3. The steam shall be released after about 30 seconds.


4. Bring your device in 20-30cm distance from your Lashes.

- When the remaining water is low, the way that the steam is emitted will change. This is not a malfunction. If more usage was desired, turn off the device, and let it cool down for 10 minutes before refilling water.
- Special notes: There's safe shut-off temperature controller, which shuts off the device when water is empty. The buzzer will keep sound and do not refill, please let it cool down for 10 minutes.

5. For safety, MCU will turn off the device automatically after working 25 minutes.

## After Use

Empty the water from the tank and the main unit after each use. Failure to do so may worsen the performance and shorten its life.



## Safety Precautions

To ensure proper operation of this appliance please carefully read all the safety precautions before using. The safety precautions are provided to help you with correct and safe operation of the appliance so that you avoid injuries to yourself and others as well as damage to property.

Always follow these important safety precautions.

The safety precautions are defined as following:

**⚠ WARNING:** This message indicates potentially hazardous actions and situations, which, if not avoided, could result in death or serious injury.

**⚠ CAUTION:** This message indicates potentially hazardous actions and situations, which, if not avoided, could result in personal injury or property damage.

### **⚠ WARNING**

- Do not use this product near a full bath, sink, or any vessel containing water.
- Do not use this appliance by persons who are unable to feel, otherwise, it may result in burns or scalding.
- Immediately stop using if you experience any pain or abnormalities on your skin or throughout your body.
- The following persons should not use this appliance:
  - Women who are pregnant or currently in a menstrual period (may cause skin problems due to hormone imbalance).
  - Persons with allergies, skin problems, such as dermatitis, severe sunburns.
  - Person with skin injuries, eczema, swelling, etc.
  - Person who are recovering after operation.
- Do not touch any metal on the electrical plug when plugging in the plug, otherwise, it may cause an accident.
- Unplug after use, otherwise, it may cause personal injury or accident.
- Turn the power off and unplug when not using, otherwise, it may result in fire or ignition.
- Periodically clean to ensure dust does not accumulate on the plug.
- Always ensure the appliance is operated on an electric power source matched to the rated voltage indicated on the appliance. Ensure that the plug is plugged in completely; otherwise, it may result in fire, electric shock, burns.
  1. When plug is loose in the power outlet conditions  
Do not use the appliance under the follow.
  2. Do not damage, modify, unreasonably bend, pull or twist the cord.
  3. Do not place anything heavy on the cord and do not pinch the cord.
  4. Do not let pins or dirt get attached to the end of the appliance plug.
- Do not plug or unplug the appliance plug into power outlets or use the appliance with wet hands.
- Do not use or store the appliance in the bathroom or in other rooms with high humidity. Humidity may cause the insulation to fail and may result in electric shocks or fire.
- Keep away from infants Do not allow infants to use the appliance. Do not allow a child to lick the appliance plug. Doing so may cause injury, electric shock or burns.
- Do not use the appliance near flammable substances (alcohol, thinner, benzene, enamel remover, aerosol sprays, etc), otherwise it may result in explosion or fire.
- Do not immerse the appliance. If the appliance sustains damage from being dropped or hit, please do not continue to use it.
- Do not insert objects in the steam outlet, and do not block the steam outlet, otherwise, it may result in explosion.
- Do not attempt to modify, disassemble, or repair the appliance.
- Contact the store where the appliance was purchased for repair, otherwise, it may cause injury due to fire or abnormal operation.

## CAUTION

Warning when using on your skin

- When disposing of the water after use, hold the appliance so that your exposed to the hot water. Initially, the appliance should only be used once a day, each time use.
- Use only distilled water or purified water. Failure to do so may result in malfunction or in serious cases, burns or scalding. Each session cannot exceed 15 minutes. For normal skin a maximum of 2 to 3 times a week and for sensitive skin, one time per week is recommended.
- Keep your hands away from the steam when operating the power switch. Keep your face and hands at least 20cm from the nozzle.
- Stop using the appliance if skin troubles occur while using the steam. Do not tilt, shake, or move the appliance during use or within 10 minutes. Doing so may cause hot water to spill out or a large volume of steam to be emitted from the steam outlet. Use on a flat surface, not for handhold.
- Do not attach, remove or install water tank during use or within 10 minutes after use. Steam continues to be emitted after the power off.

## Manufacturer's limited warranty

The Manufacturer of Facial Steamer warrants to the original purchaser of this device.

Manufacturer of Facial Steamer will, at its option, repair or replace with new or refurbished product.

The manufacturer reserves the right, before having any obligation under this limited warranty, to inspect physical, sensory or mental capabilities, or lack of experience concerning the use of the appliance by a person responsible for their safety and the damaged product.

Inspection and warranty service shall be borne solely by the purchaser.

The manufacturer's limited warranty is valid only in accordance with the correct use. The appliance should be cleaned to avoid the accumulation of following conditions: grease and other residues.

The product is purchased directly from manufacturer or an authorized reseller.

The warranty is not transferable, only the original purchaser is covered by this warranty.  
Properly dispose the package of the appliance, keep the package away from children.

This warranty is void if the product has been subject to misuse, abuse, negligence, unauthorized modification, repair or accident. Normal wear and tear are not covered by this warranty.

Purchaser must present acceptable proof of original receipt for the product. This warranty does not affect any other legal rights you may have by operation of law.

## Specifications

Voltage: 110V-/230V-

Power: 280W

Frequency: 60Hz/50Hz

Capacity: 100ml