

# 2in1 Sterilisations box with built-in Charger

## User Manual

Thank you for purchasing the 2in1 Sterilisation box.  
Please read this product specification carefully before using this product.

### Spezifische Parameter

Product name: 2in1 Sterilisation Box  
Product size: 212,3x122,3x55,5mm  
Product size interior: 193,5x99,7x32mm  
Colour: Weiß/Grau  
Input: 5V/2A9V/2A  
Rated Frequency: 110-205kHz  
Product weight: 490g  
Material: ABS+PC

### Inhalt

2in1 Sterilisation Box  
Type-C Data cable x 1

### Comptability:

Apple Telefon: iPhone 11/11 Pro  
Max/Xs/Max/Xr/X/8/8 Plus  
Samsungs Telefon: Galaxy Note 9/8/7/5/S9/S9  
Plus/S8/S8 Plus /S7/S7 edge/S6 edge plus  
All phones supporting the Qi protocol



Please pay attention to the following points, otherwise abnormal charging/disinfection may occur.

1. Please place the phone/tablet in the middle of the charging area.
2. We recommend a QC2.0/3.0 fast charging adapter.
3. Charging distance is 2-6 mm, please do not place a protective cover thicker than 3 mm while charging.
4. No metallic or magnetic objects within 6 cm of the centre of the phone during charging.
5. The lower the temperature, the faster the charging speed. The charging speed is faster in winter than in summer.
6. Press the button once briefly to sterilise for 5 minutes. Press the button twice to sterilise for 10 minutes.
7. Please do not open the lid during the disinfection process. Opening the lid automatically interrupts disinfection (UV lamps go out) to prevent UV light leakage. To disinfect again, click the button again.
8. Please do not charge the unit at high temperatures and in humid environments to avoid damage to the electrical system.

### Advice

If the cover is opened during the disinfection process, disinfection is temporarily interrupted. The UV lamp is automatically switched off to ensure that no damage is caused to the human body. The screen lights up again after the cover is closed. Press the operation button and the task will resume.

If you do not use the unit for a long time, the UV lamp may generate heat during sterilisation. After a period of approx. 10 seconds, the UV lamp switches on automatically after the preheating has been completed.

Please never open the housing yourself.

Do not use this product at high temperatures or in humid environments. Keep the unit away from heat and water.

Please never open the housing yourself.